



NLZ Built-in Motor System

SELECTION GUIDE

Rx Only

TABLE OF CONTENTS

1	Introduction.....	2
2	Symbol.....	3
3	Components	4
4	Selection Chart	7
5	NLZ Built-in Motor.....	8
5.1	One motor external I/F control	8
5.1.1	Connections.....	8
5.1.2	Wiring diagram case 1	9
6	NLZ Built-in Motor System.....	10
6.1	One motor Multi Pad2 control.....	10
6.1.1	Connections.....	10
6.1.2	Wiring diagram case 2	11
6.2	Two motors Multi Pad2 control	12
6.2.1	Connections.....	12
6.2.2	Wiring diagram case 3	13
7	Correlation of the Motor Speed and the Air Foot Control Pressure.....	14
8	Correlation of the Motor Speed and Voltage of the Speed Potentiometer (Multi Pad2, External Interface).....	15
9	Wiring Diagram Multi Pad2.....	16

1 Introduction

Please contact your agency and NSK after carefully considering the way of installing it to the chair unit by this manual.
We will offer you the best suitable set including PCB, cable with the detailed explanation.

2 Symbol



The product can be used with a washer-disinfector for thermal disinfection.



This product can be sterilized in a steam sterilizer at 135 °C.



Caution: U.S. Federal law restricts this device to sale by or on the order of a licensed physician.




Manufacturer


3 Components

NLZ BF Individual Components


- NLZ Control PCB

Control PCB (PCB with case): NLZ BF			
	MODEL NE348	ORDER CODE U1104002	Dimensions with case: W115 x D68.5 x H40 (mm)


- AC-DC Adapter PCB


AC-DC Adapter PCB (PCB with case): NLZ ADP			
	MODEL NE352	ORDER CODE U1104051	Dimensions with case: W60.2 x D81.4 x H45.2 (mm) The conversion from AC24 V to DC+32 V.

- Selector PCB







Selector PCB (PCB with case): NLZ SEL			
	MODEL NE350	ORDER CODE U1104056	Dimensions with case: W68.5 x D56.5 x H38.5 (mm)

- Micromotors and Motor Cords

Micromotor: NLZ			
	MODEL NLZ	ORDER CODE E1152051	E1152051 is autoclavable.


Motor Cord (For NLZ Micromotor): NLZ CDB			
	MODEL NLZ CDB	ORDER CODE EA1152X061	Only for NLZ, Long rear cover type Length: 2,200 mm

- Lead Connectors for NLZ BF


MOTOR HARNESS			
	MODEL MOTOR HARNESS	ORDER CODE U522057	Length: 200 mm
SENSE HARNESS			
	MODEL SENSE HARNESS	ORDER CODE U1104502	Length: 200 mm
EX-IF HARNESS			
	MODEL EX-IF HARNESS	ORDER CODE U1104501	Length: 600 mm
SELECT HARNESS			
	MODEL SELECT HARNESS	ORDER CODE 20000907	Length: 200 mm
FUSE HARNESS			
	MODEL FUSE HARNESS	ORDER CODE U1104504	Littelfuse 021506.3MXP attached. Length: 600 mm
NLZ POWER HARNESS			
	MODEL NLZ POWER HARNESS	ORDER CODE U1104500	Length: 28 mm

3 Components

Multi Pad2 Component

Display: Multi Pad2			
	MODEL Multi Pad2 Set	ORDER CODE Y1500420	Length: 1,000 mm

4 Selection Chart




5 NLZ Built-in Motor

5.1 One motor external I/F control


5.1.1 Connections

Select how to control the speed
 Case A: By the air pressure control.
 Case B: By external voltage control.

☆ : ORDER CODE



5.1.2 Wiring diagram case 1



6 NLZ Built-in Motor System

6.1 One motor Multi Pad2 control

6.1.1 Connections

Select how to control the speed


Case A: By the air pressure control.

Case B: By Multi Pad2 control. Refer to "9 Wiring Diagram Multi Pad2."


☆ : ORDER CODE

<Case A> Speed controlled by air Foot Control

- Connect the air tube from drive air to IC302 (Air pressure sensor)
 - DIP switch: Bit2 ON
 - Drive air pressure: Max 0.4MPa
- For correlation of the motor speed and the air pressure, refer to "7 Correlation of the Motor Speed and the Air Foot Control Pressure."
- Nozzle diameter of Air pressure sensor: 3mm



6.1.2 Wiring diagram case 2



Remove (or cut) unused cables to improve EMC performance.

6.2 Two motors Multi Pad2 control

6.2.1 Connections

Select how to control the speed

Case A: By the air pressure control.

Case B: By Multi Pad2 control. Refer to "9 Wiring Diagram Multi Pad2."

<Case A> Speed controlled by air Foot Control


- Connect the air tube from drive air to IC302 (Air pressure sensor)

- DIP switch: Bit2 ON


- Drive air pressure: Max 0.4MPa

For correlation of the motor speed and the air pressure, refer to "7 Correlation of the Motor Speed and the Air Foot Control Pressure."


- Nozzle diameter of Air pressure sensor: 3mm




6.2.2 Wiring diagram case 3




7 Correlation of the Motor Speed and the Air Foot Control Pressure



8 Correlation of the Motor Speed and Voltage of the Speed Potentiometer (Multi Pad2, External Interface)



9 Wiring Diagram Multi Pad2




For correlation of the potentiometer, refer to "8 Correlation of the Motor Speed and Voltage of the Speed Potentiometer (Multi Pad2, External Interface)."

<In case that the system needs to be adjusted by air pressure>

No electric wiring for the Foot Control is needed. (Wiring for the switches are needed.)

Use the air tube and connect to the IC302 of NLZ BF PCB. Also turn the Bit2 of the DIP switch ON position.



Insulate and bundle the wires which are not being used to avoid short-circuit.

